


MECHANICAL Info

Handling of MECHANICAL PP-RCT Pipes


To ensure that our MECHANICAL PP-RCT pipes operate perfectly and can be installed without any difficulties, we ask you to consider these basic points when transporting and storing the pipes.



To avoid damage of the pipes, store pipes carefully and secure the cargo.



Put down pipes or pipe bundles carefully (especially at lower temperatures).
Do not throw the pipes!



Do not use cracked and damaged pipes.
Please check before every fusion the condition of the pipes and their pipe ends.

Protect pipes from falling objects. Avoid sharp impacts and strokes to the pipes.